

Technical Datasheet Warm Wall Adhesive 5L

Warm Wall Adhesive is used to bond our revolutionary Warm Wall insulation to internal walls of masonry, plaster, brick and concrete etc. It is also used to bond the Warm Wall Skirting Channel and Warm Wall Corner Tape.

Form Supplied	Ready mixed paste
Pack Sizes	5 litres
Colour Range	Beige
Contains	Polymers and additives
Properties	Warm Wall Adhesive is a safe to use water based adhesive for bonding lightweight materials to masonry. Warm Wall Adhesive contains a powerful fungicide to protect it and the background from mould growth.
Preparation	Ensure walls are clean and sound and that all wallpaper is removed. Walls affected by black mould must be cleaned and sterilised with Radolite Concentrate. Greasy surfaces should also be cleaned using sugar soap. Porous backgrounds such as bare plaster and masonry or dusty surfaces should first be sealed with Stabilising Solution. Allow the Stabilising Solution to dry thoroughly.
General	Where Warm Wall Skirting Channel is being used, start by brushing a thin layer of Warm Wall Adhesive on to the back of the channel and fix this in place. Apply adhesive directly to the wall using either a roller or a 3mm v notched trowel. Ensure coverage is complete and even and no more adhesive than is required for one drop of Warm Wall Insulation is applied. Apply Warm Wall Insulation directly into the adhesive and smooth off ensuring full contact by pushing the insulation firmly against the wall using e.g. a clean dry roller. Make sure the insulation has been pre-cut and is ready to apply and the foam side is the one that is bonded to the wall. For external angles e.g. when fitting into window reveals, lightly brush some adhesive onto the metal side of Warm Wall Corner Tape and apply this either side of external angles. Clean off any excess adhesive with a cloth straight away. Allow the adhesive to dry for 24 – 48 hours before decorating, ideally use a heavyweight lining paper and ready mixed wallpaper paste prior to painting with Fungi-Chek to give the best results.
Coverage	5L of Warm Wall Adhesive should be sufficient to bond a 12.5m length of Warm Wall Insulation.
Cleaning	Clean equipment with soapy water before the adhesive has dried.
Storage	Between 5°C - 30°C.
Shelf Life	12 months unopened.
Limitations	For use with Warm Wall products only. For internal use only
General and Safety Precautions	Avoid skin and eye contact. Handle only when wearing protective clothing. Wash splashes from skin with soap and water, flush eyes with copious amounts of water and seek medical attention if irritation persists.

Head Office, Stathe Road, Burrowbridge, Somerset, TA7 0RY Tel: 01823 690 292 Fax: 01823 690 291

Email: info@airtechsolutions.co.uk
Web: www.airtechsolutions.co.uk